




Instruction Manual

Unique Sanitary Mixproof LP and LP-F Valve



2314-0005

ESE02021-EN2 2016-07

Original manual

The information herein is correct at the time of issue but may be subject to change without prior notice

1. EC Declaration of Conformity	4
2. Safety	5
2.1. Important information	5
2.2. Warning signs	5
2.3. Safety precautions	6
3. Installation	7
3.1. Unpacking/intermediate storage	7
3.2. General information	11
3.3. Welding	12
4. Operation	15
4.1. Operation	15
4.2. Troubleshooting and repair	16
4.3. Recommended cleaning	17
5. Maintenance	21
5.1. General maintenance	21
5.2. Dismantling of valve	25
5.3. Lower plug, replacement of radial seal	29
5.4. Upper plug, replacement of axial seal	31
5.5. Valve assembly	33
5.6. Dismantling of actuator - 4"	37
5.7. Assembly of actuator - 4"	39
5.8. Dismantling of actuator - 6"	41
5.9. Assembly of actuator - 6"	43
6. Technical data	45
6.1. Technical data	45
7. Parts list and service kits	47
7.1. Unique Mixproof LP Valve - wear parts 4" and 6"	47
7.2. Unique Mixproof LP Valve - parts - 4"	50
7.3. Unique Mixproof LP Valve - parts - 6"	52
7.4. Unique Mixproof LP Valve - service kits - 4" and 6"	54
7.5. Unique Mixproof LP-F Valve - wear parts 4" and 6"	56
7.6. Unique Mixproof LP-F Valve - parts - 4"	58
7.7. Unique Mixproof LP-F Valve - parts - 6"	60
7.8. Unique Mixproof LP-F Valve - service kits - 4" and 6"	62

1 EC Declaration of Conformity

The Designated Company

Alfa Laval Kolding A/S

Company Name

Albuen 31, DK-6000 Kolding, Denmark

Address

+45 79 32 22 00

Phone No.

hereby declare that

Valve

Designation

Unique LP, Unique LP-F

Type

From serial number 1181354 - 9999999

is in conformity with the following directive with amendments:

- Machinery Directive 2006/42/EC
- Regulation (EC) No 1935/2004
- The valve is in compliance with the Pressure Equipment Directive 2014/68/EU and was subjected to the following assessment procedure Module A. Diameters \geq DN125 may not be used for fluids group 1.

The person authorised to compile the technical file is the signer of this document

QHSE Manager, Quality, Health and safety & Environment

Title

Annie Dahl

Name

Kolding

Place

2013-03-07

Date



Signature



*Unsafe practices and other important information are emphasised in this manual.
Warnings are emphasised by means of special signs.*

2.1 Important information

Always read the manual before using the valve!

WARNING

Indicates that special procedures must be followed to avoid serious personal injury.

CAUTION

Indicates that special procedures must be followed to avoid damage to the valve.

NOTE

Indicates important information to simplify or clarify procedures.

2.2 Warning signs

General warning:



Caustic agents:



2 Safety

All warnings in the manual are summarised on this page.

Pay special attention to the instructions below so that serious personal injury and/or damage to the valve are avoided.

2.3 Safety precautions

Installation

Always read the technical data thoroughly.



Always release compressed air after use.



Never touch the clip assembly or the actuator piston rod if the actuator is supplied with compressed air (see the warning label).



Never stick your fingers through the valve ports if the actuator is supplied with compressed air.



Operation

Always read the technical data thoroughly.



Never touch the clip assembly or the actuator piston rod if the actuator is supplied with compressed air (see the warning label).



Never pressurise air connections (AC1, AC3) simultaneously as both valve plugs can be lifted (can cause mixing).



Never touch the valve or the pipelines when processing hot liquids or when sterilising.



Never throttle the leakage outlet.



Never throttle the CIP outlet, if supplied.



Always handle lye and acid with great care.



Maintenance

Always read the technical data thoroughly.



Always fit the seals correctly (risk of mixing).



Always release compressed air after use.



Always remove the CIP connections, if supplied, before service.



Never service the valve when it is hot.



Never pressurise the valve/actuator when the valve is serviced.



Never stick your fingers through the valve ports if the actuator is supplied with compressed air.



Never touch the clip assembly or the actuator piston rod if the actuator is supplied with compressed air (see the warning label).



The instruction manual is part of the delivery.

Study the instructions carefully.

Fit the warning label supplied on the valve after installation so that it is clearly visible.

3.1 Unpacking/intermediate storage

Step 1

CAUTION


Alfa Laval cannot be held responsible for incorrect unpacking.

Check the delivery for:

1. Complete valve.
2. Delivery note.
3. Warning label.

Step 2

Remove upper support.




Step 3

Lift out the valve.

NOTE!

Please note weight of valve as printed on box.



3 Installation


The instruction manual is part of the delivery.

Study the instructions carefully.

Fit the warning label supplied on the valve after installation so that it is clearly visible.


Step 4

Remove possible packing materials from the valve ports.




Step 5

Inspect the valve for visible transport damage.



Step 6

Avoid damaging the air connections, the leakage outlet, the valve ports and the CIP connections, if supplied.



The instruction manual is part of the delivery.


Study the instructions carefully.

Fit the warning label supplied on the valve after installation so that it is clearly visible.

Step 7

Disassemble according to illustrations 1 to 6 (please also see 5.2 Dismantling of valve).

1. Supply compressed air.
2. Remove upper clamp.
3. Release compressed air.
4. Lift out actuator with plugs.
5. Remove lower clamp.
6. Take away lower sealing element.



3 Installation


The instruction manual is part of the delivery.

Study the instructions carefully.

Fit the warning label supplied on the valve after installation so that it is clearly visible.

Step 8

Mount sealing element on valve.




Step 9

1. Place actuator part in the box.
2. Add supports.
3. Close box and store.

Advise!

Mark the valve body and box with the same number before intermediate storage.



Study the instructions carefully and pay special attention to the warnings!
The valve has ends for welding as standard but can also be supplied with fittings.

3.2 General information

Step 1



Always read the technical data thoroughly.



Always release compressed air after use.



Never touch the clip assembly or the actuator piston rod if the actuator is supplied with compressed air (see the warning label).

CAUTION

Fit the supplied warning label on the valve so that it is clearly visible.

CAUTION

Alfa Laval cannot be held responsible for incorrect installation.

NOTE

Always install the valve vertically.

NOTE


The leakage outlet must be turned downwards!

Step 2

Avoid stresses to the valve as this can result in deformation of the sealing area and malfunction of the valve (leakage or faulty indication).


Pay special attention to:

- Vibrations.
- Thermal expansion of the tubes.
- Excessive welding.
- Overloading of the pipelines.



Step 3


Fittings: Ensure that the connections are tight.



Step 4

Air connection: R 1/8" (BSP).

- 1: Cleaning of upper seat.
- 2: Open valve.
- 3: Cleaning of lower seat.



3 Installation

Study the instructions carefully and pay special attention to the warnings!

The valve has ends for welding as standard.

Weld carefully/aim for stressless welding to avoid deformation on sealing areas.


Check the valve for smooth operation after welding.

3.3 Welding

Step 1



Never stick your fingers through the valve ports if the actuator is supplied with compressed air.



Step 2

Dismantle the valve in accordance with step 1, section 5.2
Dismantling of valve.


Step 3

NOTE

Maintain the minimum clearances so that the actuator with the internal valve parts can be removed - please see later on in this section!



If there is a risk of foot damage, Alfa Laval recommends to leaving a distance of 120 mm below the valve (look at the specific built-in conditions).



3 Installation

Study the instructions carefully and pay special attention to the warnings!

The valve has ends for welding as standard.


Weld carefully/aim for stressless welding to avoid deformation on sealing areas.

Check the valve for smooth operation after welding.

Step 4

WARNING

Make sure to turn the valve body correctly - conical valve seat upwards.



Step 5

Assemble the valve in accordance with section 5.5 Valve assembly after welding.


Pay special attention to the warnings!

Step 6

Pre-use check:

1. Supply compressed air to AC1, AC2 and AC3 one by one.
2. Operate the valve several times to ensure that it runs smoothly.

Pay special attention to the warnings!



3 Installation

Study the instructions carefully and pay special attention to the warnings!

The valve has ends for welding as standard.

Weld carefully/aim for stressless welding to avoid deformation on sealing areas.

Check the valve for smooth operation after welding.

NOTE!

If ThinkTop® is mounted, add 180 mm to B measurement.

- A. Lower sealing element can be removed without removing actuator and internal valve parts.
- B. Actuator and internal valve parts can be lifted out of the valve body.




Table 1. Dimensions - all measures in mm

Size	4"		6"	
	LP	LP-F	LP	LP-F
A	352	274	436	342
B	1201	1201	1193	1193
**C	123.6	123.6	172.7	172.7

NOTE!

**The measurement C can always be calculated by the formula

$$C = \frac{1}{2}ID_{\text{upper}} + \frac{1}{2}ID_{\text{lower}} + 1''.$$

*The valve is adjusted and tested before delivery.
Study the instructions carefully and pay special attention to the warnings!
Pay attention to possible faults.
The items refer to the parts list and service kits section.*

4.1 Operation

Step 1



Always read the technical data thoroughly.



Always release compressed air after use.



Never touch the clip assembly or the actuator piston rod if the actuator is supplied with compressed air (see the warning label).



Never pressurise air connections (AC1, AC3) simultaneously as both valve plugs can be lifted (can cause mixing).


CAUTION

Alfa Laval cannot be held responsible for incorrect operation.

Step 2



Never touch the valve or the pipelines when processing hot liquids or when sterilising.



4 Operation

The valve is adjusted and tested before delivery.

Study the instructions carefully and pay special attention to the warnings!

Pay attention to possible faults.

The items refer to the parts list and service kits section.

4.2 Troubleshooting and repair

NOTE

Study the maintenance instructions carefully before replacing worn parts.

Problem	Cause/result	Remedy
Leakage between sealing element (79) and lower plug (75)	Worn/damaged O-rings/ lip seal (76/77/78)	<ul style="list-style-type: none"> - Replace the O-rings/lip seal - Change rubber grade - Lubricate correctly
Leakage at the leakage outlet	<ul style="list-style-type: none"> - Particles between valve seats and plug seals (56/74) - Worn/damaged plug seal rings (56/74) - Plug not assembled correctly 	<ul style="list-style-type: none"> - Remove the particles - Check the plug seals - Replace the plug seals - Change rubber grade - Assemble plug, see step 2, section 5.5 Valve assembly
Leakage at sealing element (48)/upper plug (55)	Worn/product affected O-rings/lip seal (38/39/46/49)	<ul style="list-style-type: none"> - Replace the O-rings/lip seal - Change rubber grade - Clean and if necessary replace guide ring (45)
Leakage at clamp (64)	<ul style="list-style-type: none"> - O-rings (76 and 47) too old/damaged (and 52 if clamped valve body) - Loose clamp (64) 	<ul style="list-style-type: none"> - Replace the O-rings - Change rubber grade - Tighten the clamp
CIP leakage	Worn O-rings (40/67/71)	Replace the O-rings
Leakage at spindle clamp (43)	Damaged O-ring (39) Worn/product affected lip seal (57) or spray nozzle (58)	<ul style="list-style-type: none"> - Replace the O-ring - Replace the plug seals - Change rubber grade
Lower plug not returning to closed position	<ul style="list-style-type: none"> - Wrong rubber grade - Wrongly fitted gasket - Mounted incorrectly (see section 2.3) 	<ul style="list-style-type: none"> - Change rubber grade - Fit new gasket correctly - Correct installation
Plug returns with uneven movements (slip/stick effect)	<ul style="list-style-type: none"> - Wrong rubber grade - Wrongly fitted gasket - Mounted incorrectly (see section 2.3) 	<ul style="list-style-type: none"> - Change rubber grade - Fit new gasket correctly - Correct installation

The valve is designed for cleaning in place (CIP).
Study the instructions carefully and pay special attention to the warnings!
NaOH = Caustic Soda. HNO₃ = Nitric acid.
Internal leakage in the valve is externally visible by means of the leakage outlet.

4.3 Recommended cleaning

Step 1



Never touch the valve or the pipelines when sterilising.

Caustic danger!



Always use rubber gloves!




Always use protective goggles!

Step 2



Never touch the valve or the pipelines when sterilising.



Burning danger!

4 Operation

The valve is designed for cleaning in place (CIP).

Study the instructions carefully and pay special attention to the warnings!

NaOH = Caustic Soda. HNO₃ = Nitric acid.

Internal leakage in the valve is externally visible by means of the leakage outlet.


Step 3



Never throttle the leakage outlet.



Never throttle the CIP outlet, if supplied.
(Risk of mixing due to overpressure).




Step 4



Examples of cleaning agents:

Use clean water, free from chlorides.

1. 1% by weight NaOH at 70° C



2. 0.5% by weight HNO₃ at 70° C



Step 5

1. Avoid excessive concentration of the cleaning agent

=> **Dose gradually!**

2. Adjust the cleaning flow to the process.

Milk sterilisation/viscous liquids

=> **Increase the cleaning flow!**

Step 6

Advisory seat lift cleaning periods:

Cleaning periods of 3-6 seconds per CIP sequence.

Product	Periods
Milk	1-2
Yoghurt	3-5
Beer	2-5
Cold wort	5-10

The valve is designed for cleaning in place (CIP).


Study the instructions carefully and pay special attention to the warnings!

NaOH = Caustic Soda. HNO₃ = Nitric acid.

Internal leakage in the valve is externally visible by means of the leakage outlet.

Step 7

Always rinse well with clean water after cleaning.



Step 8

NOTE

The cleaning agents must be stored/disposed of in accordance with current regulations/directives.

4 Operation

The valve is designed for cleaning in place (CIP).

Study the instructions carefully and pay special attention to the warnings!

NaOH = Caustic Soda. HNO₃ = Nitric acid.


Internal leakage in the valve is externally visible by means of the leakage outlet.

Seat-cleaning cycles:

Pay special attention to the warnings!


1. Closed valve

- A. Product
- B. CIP




2. Cleaning through lower line

- A. Product
- B. CIP




3. Open valve

- A. Product



4. Cleaning through upper line

- A. Product
- B. CIP



Maintain the valve/actuator regularly. Study the instructions carefully and pay special attention to the warnings!
Always keep spare rubber seals and guide rings in stock. The items refer to the parts list and service kits section.
The valve is designed so that internal leakages do not result in the products becoming mixed.
Internal leakage in the valve is externally visible. Check the valve for smooth operation after service.

5.1 General maintenance

Step 1



Always read the technical data thoroughly.



Always fit the seals correctly (risk of mixing).



Always release compressed air after use.



Always remove the CIP connections, if supplied, before service.

NOTE

All scrap must be stored/disposed off in accordance with current regulations/directives.


Step 2



Never service the valve when it is hot.




Never service the valve with valve/actuator under pressure.



Step 3



Never stick your fingers through the valve ports if the actuator is supplied with compressed air.




5 Maintenance

Maintain the valve/actuator regularly. Study the instructions carefully and pay special attention to the warnings! Always keep spare rubber seals and guide rings in stock. The items refer to the parts list and service kits section. The valve is designed so that internal leakages do not result in the products becoming mixed. Internal leakage in the valve is externally visible. Check the valve for smooth operation after service.

Step 4



Never touch the clip assembly or the actuator piston rod if the actuator is supplied with compressed air (see the warning label).



5 Maintenance

Maintain the valve/actuator regularly. Study the instructions carefully and pay special attention to the warnings!
 Always keep spare rubber seals and guide rings in stock. The items refer to the parts list and service kits section.
 The valve is designed so that internal leakages do not result in the products becoming mixed.
 Internal leakage in the valve is externally visible. Check the valve for smooth operation after service.

Recommended spare parts: Service kits

Order service kits from the service kits section

Ordering spare parts: Contact the Sales Department.

	Valve rubber seals	Valve plug seals	Valve guide rings
Preventive maintenance	Replace after 12 months(*)	Replace after 12 months(*)	Replace when required
Maintenance after leakage (leakage normally starts slowly)	Replace after production cycle	Replace after production cycle	
Planned maintenance	<ul style="list-style-type: none"> - Regular inspection for leakage and smooth operation - Keep a record of the valve - Use the statistics for inspection planning 	<ul style="list-style-type: none"> - Regular inspection for leakage and smooth operation - Keep a record of the valve - Use the statistics for inspection planning 	Replace when required
Lubrication	When assembling Klüber Paraliq GTE 703 or similar USDA H1 approved oil/grease (**) (suitable for EPDM)	When assembling Klüber Paraliq GTE 703 or similar USDA H1 approved oil/grease (**) (suitable for EPDM)	None

NOTE!

Lubricate thread in valve plug parts with Klüber Paste UH1 84-201 or similar.

(*) Depending on working conditions! Please contact Alfa Laval.

(**) All products wetted seals.

Repairing of actuator:

- The actuator is maintenance-free but repairable.
- If repair is required, replacing all actuator rubber seals is recommended.
- Lubricate seals with Klüberplex BE31.
- To avoid possible black marks on pos. 1 and 29, Alfa Laval recommends Klüber Paraliq GTE703 (white) for these two positions.


5 Maintenance

Maintain the valve/actuator regularly. Study the instructions carefully and pay special attention to the warnings!
Always keep spare rubber seals and guide rings in stock. The items refer to the parts list and service kits section.
The valve is designed so that internal leakages do not result in the products becoming mixed.
Internal leakage in the valve is externally visible. Check the valve for smooth operation after service.

Pre-use check

1. Supply compressed air to AC1, AC2 and AC3 one by one.
2. Operate the valve several times to ensure that it operates smoothly.

Pay special attention to the warnings!



Study the instructions carefully.
The items refer to the parts list and service kits section.
Handle scrap correctly.
Replace seals if necessary.

5.2 Dismantling of valve


(NOTE: LP-F IS SHOWN!)

Step 1

- Disassemble valve acc. to illustrations (1 to 6).
1. Supply compressed air to A2.
 2. Loosen and remove upper clamp (64).
 3. Release compressed air.
 4. Lift out the actuator together with the internal valve parts from valve body (50).
 5. Loosen and remove lower clamp (64).
 6. Remove lower sealing element (79).

NOTE

Release compressed air.



5 Maintenance

Study the instructions carefully.

The items refer to the parts list and service kits section.

Handle scrap correctly.

Replace seals if necessary.

Step 2


Unique LP

Dismantling of lower sealing element:

1. Pull out O-ring (76) and lip seal (77).

Unique LP-F

1. Pull out O-ring (76), lip seal (95) and guide ring (98) from sealing element (96+97)




Step 3

1. Supply compressed air for air connection AC1.
2. Loosen lower plug (75) while counterholding upper stem (1).
3. Remove the plug.
4. Release compressed air.

Note: For replacement of seal ring (74), please see section 4.3.

1 = on

4 = off



Study the instructions carefully.

The items refer to the parts list and service kits section.


Handle scrap correctly.

Replace seals if necessary.

Step 4

Remove coupling system and upper plug according to illustrations (1 to 4).

1. Unscrew plug (15)
2. Pull up lock (44) over piston rod (29).
3. Pull away clamps (43) from spindle liner (42).
4. Pull out upper plug (55). Make sure spindle liner is free of both piston rod and upper plug.



5 Maintenance

Study the instructions carefully.


The items refer to the parts list and service kits section.

Handle scrap correctly.

Replace seals if necessary.


Step 5

1. Remove upper sealing element (48) from upper plug (55).
2. Pull out O-ring (47) and lip seal (49) from upper sealing element.



Step 6


Remove lip seal (57) and guide ring (54). For removal and replacement of seal ring (56), please see section 5.3 Lower plug, replacement of radial seal.




Study the instructions carefully.
The items refer to the parts list and service kits section.
Handle scrap correctly.

5.3 Lower plug, replacement of radial seal

Step 1
Cut and remove old seal ring (74) using a knife, screwdriver or similar. Be careful not to scratch the plug.



Step 2
Pre-mount seal ring as shown on drawing.
Rotate along circumference to fix gasket as shown in the picture.
Carefully lubricate sealings with suitable soap or lubricant, before pre-mounting.




5 Maintenance

Study the instructions carefully.

The items refer to the parts list and service kits section.


Handle scrap correctly.

Step 3

Item No.		Tool for radial sealing, lower plug
Seat $\varnothing 143.9$	Seat $\varnothing 206.1$	
9613-4260-09	9613-4260-10	


Step 4

Place lower tool part.



Step 5


1. Place upper tool part including piston.
2. Clamp the two tool parts together.



Tool marked with item number.


Step 6

1. Supply compressed air.
2. Release compressed air.
3. Remove tool parts.



Step 7


Inspect the seal to ensure it does not twist in the groove, and press in the 4 outsticking points with a screwdriver!





Study the instructions carefully.
 The items refer to the parts list and service kits section.
 Handle scrap correctly

5.4 Upper plug, replacement of axial seal

Step 1
 Remove old seal ring (56) using a knife, screwdriver or similar. Be careful not to scratch the plug.




Step 2
 Pre-mount seal ring as shown on drawing.




Carefully lubricate sealings with suitable soap or lubricant, before pre-mounting.


Step 3

Seat $\varnothing 143.9$	Item No.	Seat $\varnothing 206.1$	Tool for axial sealing, upper plug
9613-0505-07		9613-0505-10	

Step 4
 Place tool part 1.



Step 5
 1. Place tool part 2 including piston.
 2. Clamp the two tool parts together.



5 Maintenance


Study the instructions carefully.

The items refer to the parts list and service kits section.

Handle scrap correctly


Step 6

1. Supply compressed air.
2. Release compressed air.
3. Rotate the tool 45° in relation to the plug.
4. Supply compressed air.
5. Release compressed air and remove tool.



Step 7

1. Inspect the seal.
2. Release air at 3 different positions of the circumference.



Study the instructions carefully.

The items refer to the parts list and service kits section.

Handle scrap correctly.

Replace seals if necessary.


5.5 Valve assembly

Step 1

1. Fit O-ring (47) (do not twist), and lip seal (49) in upper sealing element (48) (Lubricate with Klüber Paralique GT 703).

NOTE: The O-ring should be gently pressed into the groove


2. Fit upper sealing element in intermediate piece (37).



Step 2

1. Place lip seal (57) and guide ring (54) in upper plug and the O-ring (38) in the lower plug.
2. Press lower plug (75) rapidly into upper plug (55) through the lip seal.

Note: Do not damage the lips when lower plug (75) with O-ring (38) passes the lip seal.



5 Maintenance

Study the instructions carefully.

The items refer to the parts list and service kits section.


Handle scrap correctly.

Replace seals if necessary.

Step 3

Place coupling system and upper plug according to illustrations.

1. Push lock (44) up over piston rod (29).
2. Place spindle liner (42) on piston rod. Fit upper plug (55).
3. Mount clamps (43) on spindle liner (42).
4. Fit lock (44).
5. Fit plug (15).



Study the instructions carefully.

The items refer to the parts list and service kits section.


Handle scrap correctly.

Replace seals if necessary.

Step 4

1. Supply compressed air for air connection AC1
2. Insert lower plug (75) and tighten
3. Release compressed air

Recommended torque for fitting upper and lower plug parts: 20 Nm




Step 5

Unique LP

1. Fit lip seal (77) and O-ring (76) (do not twist the O-ring) and press it gently into the groove (lubricate with Klüber Paralique GT703)

Unique LP-F

1. Fit O-ring (76), lip seal (95) and guide ring (98) into sealing element (96+97)



5 Maintenance

Study the instructions carefully.

The items refer to the parts list and service kits section.

Handle scrap correctly.


Replace seals if necessary.

Step 6

- **Never** stick your fingers through the valve ports if the actuator is supplied with compressed air.
- **Always** supply compressed air, before demounting the valve.
- 1. Fit lower sealing element (79).
- 2. Fit and tighten lower clamp (64).
- 3. Supply compressed air (AC2) and mount the actuator together with the internal valve parts in valve body (50).
- 4. Fit and tighten upper clamp (64). Greasing of clamp and clamp nut recommended!
(Maximum torque for clamp nut: 10 Nm)
- 5. Release compressed air.


NOTE

Supply compressed air before demounting the valve.



Study the instructions carefully.
The items refer to the parts list and service kits section.
Handle scrap correctly.
Replace seals if necessary.

5.6 Dismantling of actuator - 4"



5 Maintenance

Study the instructions carefully.

The items refer to the parts list and service kits section.

Handle scrap correctly.

Replace seals if necessary.

Step 1

1. Dismantle the valve in accordance with instructions in section 5.2 Dismantling of valve

Pay special attention to the warnings!

2. The actuator is now ready for service. Please see drawing when dismantling according to steps 2 to 6 on this page.

Note! The actuator is maintenance-free but repairable.

Step 2

1. Place the actuator with intermediate piece in a vice.

2. Remove booster cylinder (126) by turning the cylinder.

Turn the cylinder until the lock ring (120) is fully removed through the groove in the cylinder and remove the cylinder.

3. Remove the bushing (128) with O-rings (129 & 130).

4. Remove the pistons (124 & 132).

5. Remove the lock ring (136) and separate the two pistons.

Remove all O-rings and bearings (122, 123, 125, 134, 131 & 133)

6. Activate main stroke (Air fitting Position 3).

7. Remove screw (135) and pull out booster spindle (127).

8. Deactivate main stroke and remove actuator from vice.

Step 3

1. Remove nuts (36) and washers (35).

2. Pull out intermediate piece (37) from the actuator.

3. Remove cover disk (25).

4. Remove retaining ring (24).

Step 4

1. Remove piston rod (29), bottom (21) and lower piston (30).

2. Separate the three parts.

3. Remove O-rings (20, 22 and 23) from bottom, O-rings (33 and 31) and guide ring (32) from lower piston as well as O-ring (28) from piston rod.

4. Remove spring assembly (14).

Step 5

1. Remove inner stem (27), main piston (17) and distance spacer (11). Remove guide ring (18) and O-ring (19)

2. Remove spring assembly (10).

Step 6

1. Unscrew screws (2) (glued!).

2. Remove stop (4).


3. Remove upper piston (8). Remove O-rings (7 and 9).

Step 7

1. Remove O-ring (5) and guide ring (6).

Study the instructions carefully.
The items refer to the parts list and service kits section.
Replace seals if necessary.
Lubricate the rubber seals before fitting them.

5.7 Assembly of actuator - 4"



TD 481-015_2

5 Maintenance

Study the instructions carefully.

The items refer to the parts list and service kits section.

Replace seals if necessary.

Lubricate the rubber seals before fitting them.

Step 1

Please see drawing when reassembling according to steps 2 to 5 on this page.

Note! The actuator is maintenance-free but repairable.

Step 2

1. Fit guide ring (6) and O-ring (5).
 2. Fit O-rings (7 and 9). Place upper piston (8).
 3. Fit stop (4).
 4. Tighten screws (2). (Secure with glue)
-

Step 3

1. Place spring assembly (10).
 2. Fit O-ring (19) and guide ring (18). Mount distance spacer (11), main piston (17) and inner stem (27).
-

Step 4

1. Fit spring assembly (14).
 2. Fit O-ring (28) in piston rod, fit O-rings (33 and 31) and guide ring (32) in lower piston and fit O-rings (20, 22 and 23) in bottom.
 3. Fit piston rod (29), lower piston (30) and bottom (21).
 4. Mount the three parts.
-

Step 5

1. Fit retaining ring (24).
 2. Fit cover disk (25).
 3. Mount intermediate piece (37) on actuator.
 4. Fit and tighten nuts (36) and washers (35).
-

Step 6

1. Place the actuator with the intermediate in a vice.
 2. Activate main stroke (air fitting position 3).
 3. Mount upper stem (127) and secure it with the screw (135).
 4. Deactivate main stroke.
-

Step 7


1. Mount O-ring and guide ring (133, 125 & 131) on inner piston (132).
 2. Mount O-ring and guide rings (125, 122, 134 & 123) on piston (124).
 3. Insert the inner piston in the piston and secure the inner piston with the lock ring (136).
 4. Mount the pistons onto the upper stem (127).
-

Step 8

1. Mount bushing (128) and O-rings (129 & 130) on the top of the cylinder.
 2. Mount the cylinder onto the cylinder (16). Rotate the cylinder until the pin hole for the lock ring (120) can be seen through the slot on the side of the cylinder.
 3. Insert the lock ring (120) in the pin hole and turn the cylinder until the complete lock ring has wandered through the slot.
 4. Remove the actuator from the vice.
-

Study the instructions carefully.
The items refer to the parts list and service kits section.
Handle scrap correctly.
Replace seals if necessary.

5.8 Dismantling of actuator - 6"



5 Maintenance

Study the instructions carefully.

The items refer to the parts list and service kits section.

Handle scrap correctly.

Replace seals if necessary.

Step 1

1. Dismantle the valve in accordance with instructions in section 4.2

Pay special attention to the warnings!

2. The actuator is now ready for service.

Please see drawing when dismantling according to steps 2 to 6 on this page.

Note! The actuator is maintenance-free but repairable.

Step 2

1. Remove nuts (36) and washers (35).

2. Pull out intermediate piece (37) from the actuator.

3. Remove cover disk (25).

4. Remove retaining ring (24).

Step 3

1. Remove piston rod (29), bottom (21) and lower piston (30).

2. Separate the three parts.

3. Remove O-rings (20, 22 and 23) from bottom, O-rings (33 and 31) and guide ring (32) from lower piston as well as O-ring (28) from piston rod.

4. Remove spring assembly (14).

Step 4

1. Remove inner stem (27), main piston (17) and distance spacer (11). Remove guide ring (18) and O-ring (19).

2. Remove spring assembly (10).

Step 5

1. Unscrew screws (2) (glued!).

2. Remove stop (4).


3. Remove upper piston (8). Remove O-rings (7 and 9).

Step 6

Remove O-ring (5) and guide ring (6).

Study the instructions carefully.
The items refer to the parts list and service kits section.
Replace seals if necessary.
Lubricate the rubber seals before fitting them.

5.9 Assembly of actuator - 6"



5 Maintenance

Study the instructions carefully.

The items refer to the parts list and service kits section.

Replace seals if necessary.

Lubricate the rubber seals before fitting them.

Step 1

Please see drawing when reassembling according to steps 2 to 5 on this page.

Note! The actuator is maintenance-free but repairable.

Step 2

1. Fit guide ring (6) and O-ring (5).
 2. Fit O-rings (7 and 9). Place upper piston (8).
 3. Fit stop (4).
 4. Tighten screws (2). (Secure with glue)
-

Step 3

1. Place spring assembly (10).
 2. Fit O-ring (19) and guide ring (18). Mount distance spacer (11), main piston (17) and inner stem (27).
-

Step 4

1. Fit spring assembly (14).
 2. Fit O-ring (28) in piston rod, fit O-rings (33 and 31) and guide ring (32) in lower piston and fit O-rings (20, 22 and 23) in bottom.
 3. Fit piston rod (29), lower piston (30) and bottom (21).
 4. Mount the three parts.
-

Step 5

1. Fit retaining ring (24).
 2. Fit cover disk (25).
 3. Mount intermediate piece (37) on actuator.
 4. Fit and tighten nuts (36) and washers (35).
-

*It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.*

6.1 Technical data

Unique Mixproof LP-F is remote-controlled by means of compressed air.

The valve is a normally closed (NC) valve. It is as standard supplied seat lift, which enables handling of two different products at the same time, or safe handling of one product while seat-lift cleaning operations are being conducted in the other portion of the valve – all without any risk of cross-contamination.

The 6" valve is as standard also equipped with balanced lower plug to protect against the effects of high pressure and water hammer.

The 4" valve is, in order to accommodate 45mm particles, not supplied with balanced lower plug.

Data	
Max. product pressure:	1000 kPa (10 bar)
Min. product pressure:	Full vacuum
Temperature range:	-5°C to +125°C (depending on rubber quality)
Air pressure:	Max. 800 kPa (8 bar)
Products acc. to PED 97/23/EC	Category I, Fluids group 1, DN ≥ 6" Fluids group 2

Size		Unique LP OD		Unique LP-F OD	
		4"	6"	4"	6"
Cv-value Upper Seat-lift	[m ³ /h]	3.2	7.1	3.2	7.1
Cv-value Lower Seat-lift	[m ³ /h]]	2.9	6.0	3.9	8.9
Air consumption Upper Seat-lift	[n litre]	0.62	0.62	0.62	0.62
Air consumption Lower Seat-lift	[n litre]	0.21	0.21	0.21	0.21
Air consumption Main Movement	[n litre]	3.54	3.54	3.54	3.54

Note! * [n litre] = volume at atmospheric pressure.

Formula to estimate CIP flow during seat lift (for liquids with comparable viscosity and density to water):

$$Q = K_v \cdot \sqrt{\Delta p}$$

$$Q = \text{CIP - flow (m}^3/\text{h)}.$$

K_v = K_v value from the above table.

$$\Delta p = \text{CIP pressure (bar)}.$$

$$Cv = 1.163 \times K_v \text{ gpm}$$

$$1 \text{ bar} = 14.5 \text{ psi}$$

6 Technical data

*It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.*

Materials	
Product wetted steel parts:	Acid-resistant steel AISI 316L.
Other steel parts:	Stainless steel AISI 304
Product wetted parts:	EPDM, HNBR, NBR or FPM.
Other seals:	CIP seals: EPDM.
Actuator seals:	NBR.
Surface finish:	Internal/external matt (blasted) Ra < 1.6 µm Internal bright (polished) Ra < 0.8 µm Internal/external bright (internal polished) Ra < 0.8 µm

Note! The Ra-values are only for the internal surface.


Weight (kg)

Size	4"	6"
Weight (kg)	64.90	86.20

7 Parts list and service kits

It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.

7.1 Unique Mixproof LP Valve - wear parts 4" and 6"



7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.*

- = Sensor kit
- = Wear parts

7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.*


Parts list

Pos.	Qty	Denomination
38	1	O-ring
47	1	O-ring
49	1	Lip seal
56	1	Seal ring
57	1	Lip seal
74	1	Seal ring
76	1	O-ring
77	1	Lip seal

7 Parts list and service kits

It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.

7.2 Unique Mixproof LP Valve - parts - 4"



2314-0003_1

○ = Wear parts

7 Parts list and service kits


*It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.*

Parts list			Parts list		
Pos.	Qty	Denomination	Pos.	Qty	Denomination
		Cpl. Actuator	32	1	Guide ring, Turcite
1	1	Upper stem	33	1	O-ring, NBR
2	4	Screw	34	3	Bolt
3	1	Air fitting	35	3	Washer
3.1	1	Air fitting	36	3	Nut
3.2	1	Air fitting	42	1	Spindle liner
3.3	1	Air fitting	43	2	Clamp
4	1	Stop for upper piston	44	1	Lock
5	1	O-ring, NBR	45	1	Guide ring, PTFE
6	1	Guide ring, Turcite	48	1	Upper sealing element
7	1	O-ring, NBR	54	1	Guide ring, PTFE
8	1	Upper piston	55	1	Upper plug
9	1	O-ring, NBR	60	2	Hexnut
10	1	Spring assembly	64	2	Clamp without nut
11	1	Distance spacer	75	1	Lower plug
12	1	Pin	79	1	Lower sealing element
13	1	Washer	80	1	Guide ring, PTFE
14	1	Spring assembly	81	1	Cover for Plug
15	3	Plug	120	1	Lock ring
16	1	Cylinder	121	1	O-ring, NBR
17	1	Main piston	122	2	Guide ring
18	1	Guide ring, Turcite	123	1	O-ring, NBR
19	1	O-ring, NBR	124	1	Piston
20	1	O-ring, NBR	125	2	O-ring, NBR
21	1	Bottom	126	1	Cylinder
22	1	Guide ring, Turcite	127	1	Upper stem, cpl.
23	1	O-ring, NBR	128	1	Bushing
24	1	Retaining ring	129	1	O-ring
25	1	Cover disk	130	1	O-ring
26	1	O-ring, NBR	131	1	Guide ring, Turcite
27	1	Inner stem	132	1	Inner piston
28	1	O-ring	133	1	O-ring
29	1	Piston rod	134	2	O-ring
30	1	Lower piston	135	1	Screw
31	1	O-ring, NBR	136	1	Lock ring

7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.*

7.3 Unique Mixproof LP Valve - parts - 6"



2314-0004_2

○ = Wear parts

7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.*


Parts list

Pos.	Qty	Denomination
1	1	Cpl. Actuator
		Upper stem
2	4	Screw
3	1	Air fitting
3.1	1	Air fitting
3.2	1	Air fitting
4	1	Stop for upper piston
5	1	O-ring, NBR
6	1	Guide ring, Turcite
7	1	O-ring, NBR
8	1	Upper piston
9	1	O-ring, NBR
10	1	Spring assembly
11	1	Distance spacer
12	1	Pin
13	1	Washer
14	1	Spring assembly
15	2	Plug
16	1	Cylinder
17	1	Main piston
18	1	Guide ring, Turcite
19	1	O-ring, NBR
20	1	O-ring, NBR
21	1	Bottom
22	1	Guide ring, Turcite
23	1	O-ring, NBR
24	1	Retaining ring
25	1	Cover disk
26	1	O-ring, NBR
27	1	Inner stem
28	1	O-ring
29	1	Piston rod
30	1	Lower piston
31	1	O-ring, NBR
32	1	Guide ring, Turcite
33	1	O-ring, NBR
34	3	Bolt
35	3	Washer
36	3	Nut
42	1	Spindle liner
43	2	Clamp
44	1	Lock
45	1	Guide ring, PTFE
48	1	Upper sealing element
54	1	Guide ring, PTFE
55	1	Upper plug
60	2	Hexnut
64	2	Clamp without nut
75	1	Lower plug
79	1	Lower sealing element
80	1	Guide ring, PTFE
81	1	Cover for Plug

7 Parts list and service kits


*It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.*

7.4 Unique Mixproof LP Valve - service kits - 4" and 6"



TD 449-014_3

Service kits



7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.*

Parts list

Pos.	Qty	Denomination
37	1	Intermediate piece
50	1	Valve body


Service kits

Denomination	4"	6"
Service kit, NBR	9611926861	9611926849
Service kit, EPDM	9611926862	9611926850
Service kit, HNBR	9611926863	9611926851
Service kit, FPM	9611926864	9611926852

7 Parts list and service kits

It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.

7.5 Unique Mixproof LP-F Valve - wear parts 4" and 6"



7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.*


Parts list

Pos.	Qty	Denomination
38	1	O-ring
47	1	O-ring
49	1	Lip seal,
56	1	Seal ring
57	1	Lip seal
74	1	Seal ring
76	1	O-ring
95	1	Special lip seal

7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.*

7.6 Unique Mixproof LP-F Valve - parts - 4"



○ = Wear parts

7 Parts list and service kits


*It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.*

Parts list			Parts list		
Pos.	Qty	Denomination	Pos.	Qty	Denomination
1	1	Cpl. Actuator	32	1	Guide ring, Turcite
2	4	Upper stem	33	1	O-ring, NBR
3	1	Screw	34	3	Bolt
3.1	1	Air fitting	35	3	Washer
3.2	1	Air fitting	36	3	Nut
3.3	1	Air fitting	42	1	Spindle liner
4	1	Stop for upper piston	43	2	Clamp
5	1	O-ring, NBR	44	1	Lock
6	1	Guide ring, Turcite	45	1	Guide ring, PTFE
7	1	O-ring, NBR	48	1	Upper sealing element
8	1	Upper piston	54	1	Guide ring, PTFE
9	1	O-ring, NBR	55	1	Upper plug
10	1	Spring assembly	60	2	Hexnut
11	1	Distance spacer	64	2	Clamp without nut
12	1	Pin	75	1	Lower plug
13	1	Washer	96	1	Lower sealing element, upper part
14	1	Spring assembly	97	1	Lower sealing element, lower part
15	3	Plug	98	1	Guide ring, Turcite
16	1	Cylinder	120	1	Lock ring
17	1	Main piston	121	1	O-ring, NBR
18	1	Guide ring, Turcite	122	2	Guide ring
19	1	O-ring, NBR	123	1	O-ring, NBR
20	1	O-ring, NBR	124	1	Piston
21	1	Bottom	125	2	O-ring, NBR
22	1	Guide ring, Turcite	126	1	Cylinder
23	1	O-ring, NBR	127	1	Upper stem, cpl.
24	1	Retaining ring	128	1	Bushing
25	1	Cover disk	129	1	O-ring
26	1	O-ring, NBR	130	1	O-ring
27	1	Inner stem	131	1	Guide ring, Turcite
28	1	O-ring	132	1	Inner piston
29	1	Piston rod	133	1	O-ring
30	1	Lower piston	134	2	O-ring
31	1	O-ring, NBR	135	1	Screw
			136	1	Lock ring

7 Parts list and service kits

It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.

7.7 Unique Mixproof LP-F Valve - parts - 6"



7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.*


Parts list

Pos.	Qty	Denomination
		Cpl. Actuator
1	1	Upper stem
2	4	Screw
3	1	Air fitting
3.1	1	Air fitting
3.2	1	Air fitting
4	1	Stop for upper piston
5	1	O-ring, NBR
6	1	Guide ring, Turcite
7	1	O-ring, NBR
8	1	Upper piston
9	1	O-ring, NBR
10	1	Spring assembly
11	1	Distance spacer
12	1	Pin
13	1	Washer
14	1	Spring assembly
15	2	Plug
16	1	Cylinder
17	1	Main piston
18	1	Guide ring, Turcite
19	1	O-ring, NBR
20	1	O-ring, NBR
21	1	Bottom
22	1	Guide ring, Turcite
23	1	O-ring, NBR
24	1	Retaining ring
25	1	Cover disk
26	1	O-ring, NBR
27	1	Inner stem
28	1	O-ring
29	1	Piston rod
30	1	Lower piston
31	1	O-ring, NBR
32	1	Guide ring, Turcite
33	1	O-ring, NBR
34	3	Bolt
35	3	Washer
36	3	Nut
42	1	Spindle liner
43	2	Clamp
44	1	Lock
45	1	Guide ring, PTFE
48	1	Upper sealing element
54	1	Guide ring, PTFE
55	1	Upper plug
60	2	Hexnut
64	2	Clamp without nut
75	1	Lower plug
96	1	Lower sealing element, upper part
97	1	Lower sealing element, lower part
98	1	Guide ring, Turcite


7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.*

7.8 Unique Mixproof LP-F Valve - service kits - 4" and 6"



Service Kits



7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform personnel about the technical data.*

Parts list

Pos.	Qty	Denomination
37	1	Intermediate piece
50	1	Valve body

Service kits

Denomination

4"

Service kit, NBR	9611926865
Service kit, EPDM	9611926866
Service kit, HNBR	9611926867
Service kit, FPM	9611926868

6"

Service kit, NBR	9611926857
Service kit, EPDM	9611926858
Service kit, HNBR	9611926859
Service kit, FPM	9611926860

How to contact Alfa Laval

Contact details for all countries are continually updated on our website.

Please visit www.alfalaval.com to access the information directly.

© Alfa Laval Corporate AB

This document and its contents is owned by Alfa Laval Corporate AB and protected by laws governing intellectual property and thereto related rights. It is the responsibility of the user of this document to comply with all applicable intellectual property laws. Without limiting any rights related to this document, no part of this document may be copied, reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the expressed permission of Alfa Laval Corporate AB. Alfa Laval Corporate AB will enforce its rights related to this document to the fullest extent of the law, including the seeking of criminal prosecution.