




# Instruction Manual

## Unique Single Seat Valve - ATEX Standard



ESE00674-EN8

2016-06

Original manual



The information herein is correct at the time of issue but may be subject to change without prior notice

|  |           |
|--|-----------|
| <b>1. EC Declaration of Conformity</b> .....         | <b>4</b>  |
| <b>2. Safety</b> .....                               | <b>5</b>  |
| 2.1. Important information .....                     | 5         |
| 2.2. Warning signs .....                             | 5         |
| 2.3. Safety precautions .....                        | 6         |
| <b>3. Installation</b> .....                         | <b>8</b>  |
| 3.1. Unpacking/delivery .....                        | 8         |
| 3.2. General installation .....                      | 10        |
| 3.3. Welding .....                                   | 11        |
| 3.4. Recycling information .....                     | 12        |
| <b>4. Operation</b> .....                            | <b>13</b> |
| 4.1. Operation .....                                 | 13        |
| 4.2. Troubleshooting .....                           | 15        |
| 4.3. Recommended cleaning .....                      | 16        |
| <b>5. Maintenance</b> .....                          | <b>18</b> |
| 5.1. General maintenance .....                       | 18        |
| 5.2. Dismantling the valve .....                     | 20        |
| 5.3. Plug seal replacement .....                     | 21        |
| 5.4. Valve assembly .....                            | 21        |
| 5.5. Actuator bushing replacement .....              | 22        |
| <b>6. Technical data</b> .....                       | <b>23</b> |
| 6.1. Technical data .....                            | 23        |
| <b>7. Parts list and service kits</b> .....          | <b>26</b> |
| 7.1. Drawing .....                                   | 26        |
| 7.2. Unique Single Seat Valve .....                  | 27        |
| 7.3. Unique Single Seat Valve - Reverse Acting ..... | 31        |

# 1 EC Declaration of Conformity

Revision of Declaration of Conformity 2009-12-29

The Designated Company

Alfa Laval Kolding A/S

Company Name

Albuen 31, DK-6000 Kolding, Denmark

Address

+45 79 32 22 00

Phone No.

hereby declare that

Valve

Designation

Unique SSV PN10

Type

From serial number 5099880 to 29999999999

is in conformity with the following directive with amendments:

- Machinery Directive 2006/42/EC
- Regulation (EC) No 1935/2004
- Pressure Equipment Directive 97/23/EC category 1 and subjected to assessment procedure Module A.
- Low Voltage Directive (LVD) 2006/95/EC
- EMC Directive 2004/108/EC
- EN 13463-1: Non-electrical equipment - Basic method and requirements
- EN 13463-5: Non-electrical equipment - Protection by constructional safety
- Technical file ref. 9612-9606. Baseefa (1180)
- The Notified Body NB.0044 will retain this Declaration of Conformity TÜV-Nord technical file no.: TÜV 08 ATEX 8000365231

If the valve is ATEX marked it is in conformity with:

- Equipment Explosive Atmospheres (ATEX) Directive 94/9/EC, valid until 2016-04-19
- Equipment Explosive Atmospheres (ATEX) Directive 2014/34/EC, valid from 2016-04-20

The person authorised to compile the technical file is the signer of this document

Global Product Quality Manager  
Pumps, Valves, Fittings and Tank Equipment

Title

Lars Kruse Andersen

Name

Kolding

Place

2013-12-03

Date

Signature



*Unsafe practices and other important information are emphasised in this manual.  
Warnings are emphasised by means of special signs.*

---

### 2.1 Important information

---

**Always read the manual before using the valve!**

**WARNING**

Indicates that special procedures must be followed to avoid serious personal injury.

**CAUTION**

Indicates that special procedures must be followed to avoid damage to the valve.

**NOTE**

Indicates important information to simplify or clarify procedures.

---

### 2.2 Warning signs

---

General warning:



Caustic agents:



## 2 Safety


All warnings in this manual are summarised on this page.

Pay special attention to this instructions below so that severe personal injury and/or damage to the valve are avoided.

### 2.3 Safety precautions

#### Actuators marked with year 2012 (new actuator design):

Alfa Laval recommends not to exceed 3 bar support air on the spring side in all the Unique SSV actuators, to ensure 10 bar product pressure without leakage. Plastic adapter (pos. 5) is always used on the new design.



#### Actuators marked with year 2006-2011 (old actuator design):




#### WARNING!

When using "support air" on spring side in all the Unique SSV actuators, the pressure must **NOT** exceed 3 bar.

When using Unique SSV actuators with ø156mm with support air, **always** use the "steel adapter" (pos. 5). Tighten the "steel adapter" to a torque of 30 Nm and use Loctite 243.

The actuator with ø156mm is mainly used on valves ISO76/DN80 – ISO101/DN100. The outer actuator diameter = ø156 mm.



---

All warnings in this manual are summarised on this page.

Pay special attention to this instructions below so that severe personal injury and/or damage to the valve are avoided.

---

### Installation:

**Always** read the technical data thoroughly (see chapter 6 Technical data)  
**Always** release compressed air after use  
**Never** touch moving parts if the actuator is supplied with compressed air  
**Never** touch the valve or the pipelines when processing hot liquids or when sterilising  
**Never** dismantle the valve with valve and pipelines under pressure  
**Never** dismantle the valve when it is hot



---

### Operation:

**Never** dismantle the valve with valve and pipelines under pressure  
**Never** dismantle the valve when it is hot  
**Always** read the technical data thoroughly (see chapter 6 Technical data)  
**Always** release compressed air after use  
**Never** touch the valve or the pipelines when processing hot liquids or when sterilising  
**Never** touch moving parts if the actuator is supplied with compressed air  
**Always** rinse well with clean water after cleaning



**Always** handle lye and acid with great care



---

### Maintenance:

**Always** read the technical data thoroughly (see chapter 6 Technical data)  
**Always** release compressed air after use  
**Never** service the valve when it is hot  
**Never** service the valve with valve and pipelines under pressure  
**Never** stick your fingers through the valve ports if the actuator is supplied with compressed air  
**Never** touch moving parts if the actuator is supplied with compressed air



---

### Transportation:

**Always** ensure that compressed air are released  
**Always** ensure that all connections is disconnected before attempting to remove the valve from the installation  
**Always** drain liquid out of valves before transportation

**Always** used predesigned lifting points if defined  
**Always** ensure sufficient fixing of the valve during transportation - if specially designed packaging material is available, it must be used

---

### 3 Installation

The instruction manual is part of the delivery. Study the instructions carefully.

The items refer to parts list and service kits section.

The valve is supplied as separate parts as standard (for welding).

The valve is assembled before delivery, if it is supplied with fittings.

#### 3.1 Unpacking/delivery

##### Step 1

##### CAUTION

Alfa Laval cannot be held responsible for incorrect unpacking.

##### Check the delivery for:


1. Complete valve, shut-off valve (RA) or change-over valve (RA) (see steps 2a, 2b, 2c and 2d).
2. Delivery note.

##### Step 2

##### 2a

##### Shut-off valve:

1. Complete actuator.
2. Bonnet (20).
3. Clamp (19).
4. Valve plug (23).
5. Valve body (22).
6. Ground wire (64).




TD 461-943

##### 2b

##### Change-over valve:

1. Complete actuator.
2. Bonnet (20).
3. 2 x clamps (19).
4. Valve plug (27).
5. Lower valve body (22).
6. Valve seat (28).
7. Upper valve body (26).
8. Ground wire (64).




TD 461-944\_1

##### 2c

##### Shut-off valve - Reverse Acting:

1. Complete actuator.
2. Bonnet (20).
3. 3 x clamps (19).
4. Valve plug (23).
5. 2 x upper valve bodies (26).
6. Valve seat (28).
7. Lower bonnet (33).
8. Ground wire (64).



TD 461-945\_1



The instruction manual is part of the delivery. Study the instructions carefully.

The items refer to parts list and service kits section.


The valve is supplied as separate parts as standard (for welding).

The valve is assembled before delivery, if it is supplied with fittings.

### 2d

#### Change-over valve - Reverse Acting:

1. Complete actuator.
2. Bonnet (20).
3. 4 x clamps (19).
4. Upper valve plug (34).
5. Lower valve plug (35).
6. 3 x upper valve bodies (26).
7. 2 x valve seats (28).
8. Lower bonnet (33).
9. Ground wire (64).



### Step 3

Remove possible packing materials from the valve/valve parts.

Inspect the valve/valve parts for visible transport damage.

Avoid damaging the valve/valve parts.

### 3 Installation

Study the instructions carefully and pay special attention to the warnings!  
The valve has welding ends as standard but can also be supplied with fittings.

#### 3.2 General installation

##### Step 1



**Always** read the technical data thoroughly.  
See chapter 6 Technical data.



**Always** release compressed air after use.


##### CAUTION

Alfa Laval cannot be held responsible for incorrect installation.

##### Step 2




**Never** touch the moving parts if the actuator is supplied with compressed air.



##### Step 3

It is recommended to install the valve so that the flow is against the closing direction to avoid water hammering.

Shock in the actuator must **never** occur.




Study the instructions carefully.  
 The valve is supplied as separate parts to facilitate the welding.  
 The items refer to the parts list and service kits section.  
 Check the valve for smooth operation after welding.

#### Step 4

Avoid stressing the valve.

#### Pay special attention to:

- Vibrations.
- Thermal expansion of the pipelines.
- Excessive welding.
- Overloading of the pipelines.



Risk of damage!


### 3.3 Welding

#### Step 1

**Always** install valves with more than one valve body so that the seals between the valve bodies can be replaced. Do not weld more than one valve body into the system.

| Valve size     | A (mm) | B (mm) |
|----------------|--------|--------|
| DN25/25 mm     | *      | 630    |
| DN40/38 mm     | *      | 700    |
| DN50/51 mm     | *      | 750    |
| DN65/63.5 mm   | *      | 740    |
| DN80/76 mm     | *      | 800    |
| DN100/101.6 mm | *      | 790    |

\* Depending on body combination and piping solution.




B (incl. top unit)

A\*

#### Step 2

Assemble the valve in accordance with the steps on page 21.

**Pay special attention to the warnings!**



### 3 Installation

---

Study the instructions carefully.

The valve is supplied as separate parts to facilitate the welding.

The items refer to the parts list and service kits section.

Check the valve for smooth operation after welding.


---

#### Step 3

##### Pre-use check:

1. Supply compressed air to the actuator.
2. Open and close the valve several times to ensure that it operates smoothly.

##### Pay special attention to the warnings!



---

#### Step 4

Make sure the ground wire has electrical connection to plug and actuator.



All conducting parts or equipment must be arranged to avoid that a dangerous potential difference can exist between them. If there is a possibility of isolated metal parts becoming charged and acting as an ignition source, then earthing terminals must be provided.

---

### 3.4 Recycling information

---

#### • Unpacking

- Packing material consists of wood, plastics, cardboard boxes and in some cases metal straps
- Wood and cardboard boxes can be re-used, recycled or used for energy recovery
- Plastics should be recycled or burnt at a licensed waste incineration plant
- Metal straps should be sent for material recycling

#### • Maintenance

- During maintenance, oil and wearing parts in the machine are replaced
- All metal parts should be sent for material recycling
- Worn out or defective electronic parts should be sent to a licensed handler for material recycling
- Oil and all non-metal wear parts must be disposed off in agreement with local regulations

#### • Scrapping

- At end of use, the equipment must be recycled according to the relevant, local regulations. Besides the equipment itself, any hazardous residues from the process liquid must be considered and dealt with in a proper manner. When in doubt, or in the absence of local regulations, please contact your local Alfa Laval sales company
-

Study the instructions carefully and pay special attention to the warnings!  
 Ensure that the valve operates smoothly.  
 The items refer to the parts list and service kits section.

### 4.1 Operation

#### Step 1



**Always** read the technical data thoroughly.  
 See chapter 6 Technical data.



**Always** release compressed air after use.


#### CAUTION

Alfa Laval cannot be held responsible for incorrect operation.

#### Step 2




**Never** touch the valve or the pipelines when processing hot liquids or when sterilising.



#### Step 3




**Never** touch moving parts if the actuator is supplied with compressed air.



#### Step 4

##### Lubrication of valves:

1. Ensure smooth movement between lip seal (25) and plug stem (23, 27).
2. Lubricate the lip seal with Klüber Paraliq GTE 703 if necessary (see page 18).



## 4 Operation

---

*Study the instructions carefully and pay special attention to the warnings!*

*Ensure that the valve operates smoothly.*


*The items refer to the parts list and service kits section.*

---

### Step 5

#### Lubrication of actuator

1. Ensure smooth movement of the actuator (the actuator is lubricated before delivery).
2. Lubricate all seals with Molykote Longterm 2 plus if necessary.



Pay attention to possible faults. Study the instructions carefully.  
The items refer to the parts list and service kits section.

## 4.2 Troubleshooting

### NOTE!

Study the maintenance instructions carefully before replacing worn parts - see page 18!

| Problem                       | Cause/result  | Repair   |
|-------------------------------|---|--|
| External product leakage      | Worn or product affected lip seal and/or O-ring   | <ul style="list-style-type: none"> <li>- Replace the seals</li> <li>- Replace with seals of a different rubber grade</li> </ul>  |
| Internal product leakage      | <ul style="list-style-type: none"> <li>- Worn or product affected plug seal</li> <li>- Product deposits on the seat and/or plug</li> <li>- Product pressure exceeds actuator specification</li> </ul> | <ul style="list-style-type: none"> <li>- Replace the seal</li> <li>- Replace with a seal of a different rubber grade</li> <li>- Frequent cleaning</li> <li>- Replace with a high pressure actuator</li> <li>- Use auxiliary air on the spring side (do not exceed 3 bar)</li> <li>- Reduce product pressure</li> </ul> |
| Water hammer                  | The flow direction is the same as the closing direction   | <ul style="list-style-type: none"> <li>- The flow direction should be against the closing direction</li> <li>- Throttle air release of solenoid in top unit</li> </ul>   |
| The valve does not open/close | Product pressure exceeds actuator specification   | <ul style="list-style-type: none"> <li>- Replace with a high pressure actuator</li> <li>- Use auxiliary air on the spring side</li> <li>- Reduce product pressure</li> </ul>   |

## 4 Operation

The valve is designed for cleaning in place (CIP).

Study the instructions carefully and pay special attention to the warnings!

NaOH = Caustic Soda.

HNO<sub>3</sub> = Nitric acid.

### 4.3 Recommended cleaning

#### Step 1



Always handle lye and acid with great care.

Caustic danger!



Always use rubber gloves!




Always use protective goggles!


#### Step 2



Never touch the valve or the pipelines when sterilising.



Burn hazard!




#### Step 3

Clean the plug and the seats correctly.

Pay special attention to the warnings!


Lift and lower valve plug momentarily

Shut-off valve



TD 461-031

Change-over valve



TD 461-029

#### Step 4

Examples of cleaning agents:

Use clean water, free from chlorides.

1. 1% by weight NaOH at 70° C

1 kg NaOH + 100 l water = Cleaning agent.

2.2 l 33% NaOH + 100 l water = Cleaning agent.

2. 0.5% by weight HNO<sub>3</sub> at 70° C

0.7 l 53% HNO<sub>3</sub> + 100 l water = Cleaning agent.



*The valve is designed for cleaning in place (CIP).*

*Study the instructions carefully and pay special attention to the warnings!*


*NaOH = Caustic Soda.*

*HNO<sub>3</sub> = Nitric acid.*

---

### Step 5

1. Avoid excessive concentration of the cleaning agent.
2. Adjust the cleaning flow to the process.
3. **Always** rinse well with clean water after the cleaning.



Clean water    Cleaning agents

---

### Step 6

#### NOTE

The cleaning agents must be stored/disposed of in accordance with current regulations/directives.

---

### Step 7



#### Dust cleaning!

To avoid damage, all seal openings must be held free for dust. All surfaces must be cleaned for dust.

---

## 5 Maintenance

Maintain the valve regularly.

Study the instructions carefully and pay special attention to the warnings!

Always keep spare rubber seals and lip seals in stock.

Check the valve for smooth operation after service.

### 5.1 General maintenance

#### Step 1



**Always** read the technical data thoroughly.  
See chapter 6 Technical data.



**Always** release compressed air after use.

#### Step 2




**Never** service the valve when it is hot.



**Never** service the valve with valve and pipelines under pressure.

#### NOTE

All scrap must be stored/discharged in accordance with current rules/directives.




#### Step 3



**Never** stick your fingers through the valve ports if the actuator is supplied with compressed air.

**Never** touch the moving parts if the actuator is supplied with compressed air.



Maintain the valve regularly.

Study the instructions carefully and pay special attention to the warnings!

Always keep spare rubber seals and lip seals in stock.

Check the valve for smooth operation after service.


Below are some guidelines for maintenance and lubrication intervals. Please note that the guidelines are for normal working conditions in one shift.

|  | Product wetted seals   | Actuator bushings complete  |
|--|--|---|
| Preventive maintenance                                     | Replace after 12 months depending on working conditions  | Replace with Service Kit or complete ATEX actuator after 5 years depending on working conditions  |
| Maintenance after leakage (leakage normally starts slowly) | Replace at the end of the day  | Replace when possible   |
| Planned maintenance  | <ul style="list-style-type: none"> <li>- Regular inspection for leakage and smooth operation</li> <li>- Keep a record of the valve</li> <li>- Use the statistics for inspection planning</li> </ul> <b>Replace after leakage</b> | <ul style="list-style-type: none"> <li>- Regular inspection for leakage and smooth operation</li> <li>- Keep a record of the actuator</li> <li>- Use the statistics for inspection planning</li> </ul> <b>Replace after leakage</b> |
| Lubrication  | <b>Before fitting</b><br>Klüber Paraliq GTE 703 or similar USDA H1 approved oil/grease   | <b>Before fitting</b><br>Molykote Longterm 2 plus   |

### Pre-use check:

1. Supply compressed air to the actuator.
2. Open and close the valve several times to ensure that it operates smoothly.

**Pay special attention to the warnings!**



### Recommended spare parts

Service kits (see page 26)

## 5 Maintenance

Study the instructions carefully. The items refer to the parts list and service kits section. Handle scrap correctly.

NC = Normally closed.

NO = Normally open.

A/A = Air/air activated.

### 5.2 Dismantling the valve

#### Step 1

##### 1a


##### Shut-off valve:

1. Supply compressed air to the actuator (only NC).
2. Loosen and remove clamp.
3. Release compressed air (only NC).
4. Lift away the actuator.
5. Unscrew and remove valve plug.
6. Remove ground wire terminal from valve plug.
7. Remove O-ring, lip seal and bushing in bonnet.  
(Use bushing tool and rubber mallet).

**Note!** Be careful not to damage the bushing.

##### Pay special attention to the warnings!

**Note!** For plug seal replacement please read instruction in service kit.



##### Note!

Be careful not to damage the bushing.

##### 1b


##### Change-over valve:

1. Supply compressed air to the actuator (only NC).
2. Loosen and remove lower clamp.
3. Release compressed air (only NC).
4. Lift away the actuator and upper valve body.
5. Supply compressed air to the actuator (only NO).
6. Unscrew and remove valve plug.
7. Remove ground wire terminal from valve plug.
8. Release compressed air (only NO).
9. Remove seat and O-rings.
10. Loosen and remove upper clamp.
11. Remove upper valve body.
12. Remove O-ring, lip seal and bushing in bonnet.  
(Use bushing tool and rubber mallet.  
See drawing, step 1a).

**Note!** Be careful not to damage the bushing.

##### Pay special attention to the warnings!

**Note!** For plug seal replacement please read instruction in service kit.



##### 1c


##### Shut-off valve - Reverse Acting:

1. Loosen and remove lower clamp.
2. Remove lower bonnet and O-ring from lower body.
3. Loosen and remove middle clamp.
4. Lift away the actuator and upper valve body.
5. Supply compressed air to the actuator (only NC).
6. Unscrew and remove valve plug.
7. Release compressed air (only NC).
8. Remove seat and O-rings.
9. Loosen and remove upper clamp.
10. Remove upper valve body.
11. Remove O-ring, lip seal and bushing in bonnet.  
(Use bushing tool and rubber mallet.  
See drawing, step 1a).

**Note!** Be careful not to damage the bushing.

##### Pay special attention to the warnings!

**Note!** For plug seal replacement please read instruction in service kit.



Study the instructions carefully. The items refer to the parts list and service kits section. Handle scrap correctly.

NC = Normally closed.

NO = Normally open.

A/A = Air/air activated.

### 1d


#### Change-over valve - Reverse Acting:

1. Loosen and remove lower clamp.
2. Remove lower bonnet and O-ring.
3. Loosen and remove clamp between lower and middle valve body
4. Lift away the actuator and upper + middle valve body.
5. Supply compressed air to the actuator (only NC).
6. Unscrew and remove lower valve plug.
7. Release compressed air (only NC).
8. Remove lower seat and O-rings.
9. Supply compressed air to the actuator (only NO).
10. Loosen and remove clamp between middle and upper valve body.
11. Remove middle valve body and upper seat with O-rings.
12. Release compressed air (only NO).
13. Loosen and remove upper clamp.
14. Remove upper valve body.
15. Unscrew and remove upper valve plug.
16. Remove O-ring, lip seal and bushing in bonnet.  
(Use bushing tool and rubber mallet. See drawing, step 1a).

**Note!** Be careful not to damage the bushing.

**Pay special attention to the warnings!**

**Note!** For plug seal replacement please read instruction in service kit.



### 5.3 Plug seal replacement

1. Remove old seal ring using a knife, screwdriver or similar.  
Be careful not to damage metal parts.
2. Pre-mount plug seal without pressing it into the groove.
3. Squeeze plug seal into the groove using opposite pressure points.
4. Release compressed air behind plug seal.

**Note!** For plug seal replacement, please read the instructions in the service kit.

### 5.4 Valve assembly

Reverse order of 5.2 Dismantling the valve.

Lubricate O-ring (21) and lip seal (25) with Klüber Paraliq GTE 703.

Remember to tighten spindle and plug with to a torque of **30Nm** (to use two 17mm spanners) .

If there are vibrations in the pipeline Alfa Laval recommend using loctite no. 243.

The clamps thread must be lubricated before tightening - max. torque for the clamps is 10-12 Nm.

## 5 Maintenance

---

Study the instructions carefully.

The items refer to the parts list and service kits section. Handle scrap correctly.

AVA = Air/air activated.


Service tool: See Spare Parts.

---

### 5.5 Actuator bushing replacement

---

1. Unscrew and remove top and bottom bushings with O-rings.
2. Lubricate O-rings with Molykote Longterm 2 plus before fitting.
3. Fit bushings and O-rings. Tighten bushing to a torque of 10Nm.  
Be careful not to overtighten.



TD 461-310

---

*It is important to observe the technical data during installation, operation and maintenance.  
Inform all personnel about the technical data.*

### 6.1 Technical data

The valve is a pneumatic seat valve in a hygienic and modular design for a wide field of duties, e.g. as a shut-off valve with two (2) or three (3) ports or as a change-over valve with three (3) to five (5) ports.

The valve is remote-controlled by means of compressed air. It has few and simple moveable parts which results in a very reliable valve and low maintenance cost.

Standard design The Unique SSV ATEX valve comes in a one or two body configuration. With its module built structure it is designed for flexibility and easy customization through the electronic configurator.

| Data - valve/actuator         |  |
|-------------------------------|--|
| Max. product pressure         | 1000 kPa (10 bar).                                 |
| Min. product pressure         | Full vacuum (depending on product specifications). |
| Temperature range             | -10° C to + 140° C (standard EPDM seal).           |
| Air pressure, actuator        | 500 to 700 kPa (5 to 7 bar).                       |
| Materials - valve/actuator    |  |
| Product wetted steel parts    | 1.4404 (316L) (internal Ra < 0.8 µm).              |
| Other steel parts             | 1.4301 (304).                                      |
| Plug seal                     | EPDM / PTFE (TR2).                                 |
| Other product wetted seals    | EPDM (standard).                                   |
| Optional product wetted seals | HNBR and FPM.                                      |
| Other seals                   | NBR.   |

#### Weight (kg)

| Nominal Size      | Inch tubes<br>DN/OD |     |     |      |      |       | DIN tubes<br>DN |     |     |     |      |      |
|-------------------|---------------------|-----|-----|------|------|-------|-----------------|-----|-----|-----|------|------|
|                   | 25                  | 38  | 51  | 63.5 | 76.1 | 101.6 | 25              | 40  | 50  | 65  | 80   | 100  |
| Shut-off valve    | 3.1                 | 3.3 | 5.5 | 6.5  | 11.3 | 13.6  | 3.2             | 3.4 | 5.5 | 6.6 | 11.8 | 13.6 |
| Change-over valve | 3.9                 | 4.2 | 7.1 | 8.5  | 14   | 18    | 4.1             | 4.5 | 7.2 | 8.8 | 14.9 | 17.9 |

#### Noise

One metre away from and 1.6 metres above the exhaust the noise level of a valve actuator will be approximately 77db (A) without noise damper and approximately 72 db (A) with damper - measured at 7 bar air-pressure.





## 6 Technical data

---

*It is important to observe the technical data during installation, operation and maintenance.  
Inform all personnel about the technical data.*




---

---


## 7 Parts list and service kits

The drawing shows Unique Single Seat Valve.  
The items refer to the parts list in the following sections

### 7.1 Drawing



Shut-off valve - Reverse Acting




Change-over valve - Reverse Acting

### 7.2 Unique Single Seat Valve

## 7 Parts list and service kits

The drawing shows Unique Single Seat Valve.  
The items refer to the parts list in the following sections



## 7 Parts list and service kits

The drawing shows Unique Single Seat Valve.  
The items refer to the parts list in the following sections

### Parts list

| Pos.   | Qty  | Denomination |
|--------|------|--------------|
| 5      | 1    | Actuator     |
| 6 □    | 2    | Adapter      |
| 7 □    | 2    | Bushing      |
| 8 □    | 2    | O-ring       |
| 9      | 1    | O-ring       |
| 12     | 1(2) | Plug         |
| 19     | 1    | Air fitting  |
| 20     | 1    | Clamp        |
| 21 ♦   | 1    | Bonnet       |
| 22     | 1    | O-ring       |
| 23     | 1    | Valve body   |
| 23.1   | 1    | Plug         |
| 23.2 ♦ | 1    | Plug seal    |
| 24     | 1    | Bushing      |
| 25 ♦   | 1    | Lip seal     |

### Service kits


| Denomination  | DN 25<br>25 mm | DN 40<br>38 mm | DN 50<br>51 mm | DN 65<br>63.5 mm | DN 80<br>76.1 mm | DN 100<br>101.6 mm |
|---|----------------|----------------|----------------|------------------|------------------|--------------------|
| <b>Service kit for actuator</b>                       |                |                |                |                  |                  |                    |
| □ Service kit, actuator .....                         | 9611926500     | 9611926500     | 9611926500     | 9611926500       | 9611926500       | 9611926500         |
| <b>Service kit for product wetted parts, standard</b> |                |                |                |                  |                  |                    |
| ♦ Service kit, EPDM .....                             | 9611926501     | 9611926502     | 9611926503     | 9611926504       | 9611926505       | 9611926506         |
| ♦ Service kit, HNBR .....                             | 9611926507     | 9611926508     | 9611926509     | 9611926510       | 9611926511       | 9611926512         |
| ♦ Service kit, FPM .....                              | 9611926513     | 9611926514     | 9611926515     | 9611926516       | 9611926517       | 9611926518         |

Parts marked with □ are included in the service kits (actuator)  
Parts marked with ♦ are included in the service kits (product wetted parts)  
Tool for bushing (pos. 24) - item no: 9613160901

TD 900254/2

## 7 Parts list and service kits

The drawing shows Unique Single Seat Valve.  
The items refer to the parts list in the following sections



## 7 Parts list and service kits

The drawing shows Unique Single Seat Valve.  
The items refer to the parts list in the following sections

### Parts list

| Pos.   | Qty  | Denomination |
|--------|------|--------------|
| 5      | 1    | Adapter      |
| 6 □    | 2    | Bushing      |
| 7 □    | 2    | O-ring       |
| 8 □    | 2    | O-ring       |
| 9      | 1    | Plug         |
| 12     | 1(2) | Air fitting  |
| 19     | 2    | Clamp        |
| 20     | 1    | Bonnet       |
| 21 ♦   | 3    | O-ring       |
| 22     | 1    | Valve body   |
| 24     | 1    | Bushing      |
| 25 ♦   | 1    | Lip seal     |
| 26     | 1    | Valve body   |
| 27     | 1    | Plug         |
| 27.1   | 1    | Plug         |
| 27.2 ♦ | 2    | Plug seal    |
| 28     | 1    | Seat         |

### Service kits

#### Service kit for actuator

|   |                             |            |            |            |            |            |            |
|---|-----------------------------|------------|------------|------------|------------|------------|------------|
| □ | Service kit, actuator ..... | 9611926500 | 9611926500 | 9611926500 | 9611926500 | 9611926500 | 9611926500 |
|---|-----------------------------|------------|------------|------------|------------|------------|------------|

#### Service kit for product wetted parts, standard

|   |                         |            |            |            |            |            |            |
|---|-------------------------|------------|------------|------------|------------|------------|------------|
| ♦ | Service kit, EPDM ..... | 9611926579 | 9611926580 | 9611926581 | 9611926582 | 9611926583 | 9611926584 |
| ♦ | Service kit, HNBR ..... | 9611926585 | 9611926586 | 9611926587 | 9611926588 | 9611926589 | 9611926590 |
| ♦ | Service kit, FPM .....  | 9611926591 | 9611926592 | 9611926593 | 9611926594 | 9611926595 | 9611926596 |

Parts marked with □ are included in the service kits (actuator)


Parts marked with ♦ are included in the service kits (product wetted parts)

TD 900254/2

## 7 Parts list and service kits

The drawing shows Unique Single Seat Valve.  
The items refer to the parts list in the following sections

### 7.3 Unique Single Seat Valve - Reverse Acting



## 7 Parts list and service kits

The drawing shows Unique Single Seat Valve.  
The items refer to the parts list in the following sections

### Parts list

| Pos.   | Qty  | Denomination |
|--------|------|--------------|
| 5      | 1    | Adapter      |
| 6 □    | 2    | Bushing      |
| 7 □    | 2    | O-ring       |
| 8 □    | 2    | O-ring       |
| 9      | 1    | Plug         |
| 12     | 1(2) | Air fitting  |
| 19     | 3    | Clamp        |
| 20     | 1    | Bonnet       |
| 21 ♦   | 4    | O-ring       |
| 23     | 1    | Plug         |
| 23.1   | 1    | Plug         |
| 23.2 ♦ | 1    | Plug seal    |
| 24     | 1    | Bushing      |
| 25 ♦   | 1    | Lip seal     |
| 26     | 2    | Valve body   |
| 28     | 1    | Seat         |
| 33     | 1    | Lower bonnet |

### Service kits

| Denomination  | DN 25<br>25 mm | DN 40<br>38 mm | DN 50<br>51 mm | DN 65<br>63.5 mm | DN 80<br>76.1 mm | DN 100<br>101.6 mm |
|---|----------------|----------------|----------------|------------------|------------------|--------------------|
| <b>Service kit for actuator</b>                       |                |                |                |                  |                  |                    |
| □ Service kit .....                                   | 9611926500     | 9611926500     | 9611926500     | 9611926500       | 9611926500       | 9611926500         |
| <b>Service kit for product wetted parts, standard</b> |                |                |                |                  |                  |                    |
| ♦ Service kit, EPDM .....                             | 9611926525     | 9611926526     | 9611926527     | 9611926528       | 9611926529       | 9611926530         |
| ♦ Service kit, HNBR .....                             | 9611926531     | 9611926532     | 9611926533     | 9611926534       | 9611926535       | 9611926536         |
| ♦ Service kit, FPM .....                              | 9611926537     | 9611926538     | 9611926539     | 9611926540       | 9611926541       | 9611926542         |

Parts marked with □♦ are included in the service kits.


Recommended spare parts: Service kits.

TD 900-350/1



## 7 Parts list and service kits

The drawing shows Unique Single Seat Valve.  
The items refer to the parts list in the following sections



## 7 Parts list and service kits

The drawing shows Unique Single Seat Valve.  
The items refer to the parts list in the following sections

### Parts list

| Pos.   | Qty  | Denomination |
|--------|------|--------------|
| 5      | 1    | Adapter      |
| 6 □    | 2    | Bushing      |
| 7 □    | 2    | O-ring       |
| 8 □    | 2    | O-ring       |
| 9      | 1    | Plug         |
| 12     | 1(2) | Air fitting  |
| 19     | 4    | Clamp        |
| 20     | 1    | Bonnet       |
| 21 ♦   | 6    | O-ring       |
| 24     | 1    | Bushing      |
| 25 ♦   | 1    | Lip seal     |
| 26     | 3    | Valve body   |
| 28     | 2    | Seat         |
| 33     | 1    | Lower bonnet |
| 34     | 1    | Plug         |
| 34.1   | 1    | Plug         |
| 34.2 ♦ | 1    | Plug seal    |
| 34.3 ♦ | 1    | O-ring       |
| 35     | 1    | Plug         |
| 35.1   | 1    | Plug         |
| 35.2 ♦ | 1    | Plug seal    |

### Service kits

| Denomination  | DN 25<br>25 mm | DN 40<br>38 mm | DN 50<br>51 mm | DN 65<br>63.5 mm | DN 80<br>76.1 mm | DN 100<br>101.6 mm |
|---|----------------|----------------|----------------|------------------|------------------|--------------------|
| <b>Service kit for actuator</b>                       |                |                |                |                  |                  |                    |
| □ Service kit .....                                   | 9611926500     | 9611926500     | 9611926500     | 9611926500       | 9611926500       | 9611926500         |
| <b>Service kit for product wetted parts, standard</b> |                |                |                |                  |                  |                    |
| ♦ Service kit, EPDM .....                             | 9611926597     | 9611926598     | 9611926599     | 9611926600       | 9611926601       | 9611926602         |
| ♦ Service kit, HNBR .....                             | 9611926603     | 9611926604     | 9611926605     | 9611926606       | 9611926607       | 9611926608         |
| ♦ Service kit, FPM .....                              | 9611926609     | 9611926610     | 9611926611     | 9611926612       | 9611926613       | 9611926614         |

Parts marked with □♦ are included in the service kits.  
Recommended spare parts: Service kits.



**How to contact Alfa Laval**

Contact details for all countries are continually updated on our website.

Please visit [www.alfalaval.com](http://www.alfalaval.com) to access the information directly.

© Alfa Laval Corporate AB

This document and its contents is owned by Alfa Laval Corporate AB and protected by laws governing intellectual property and thereto related rights. It is the responsibility of the user of this document to comply with all applicable intellectual property laws. Without limiting any rights related to this document, no part of this document may be copied, reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the expressed permission of Alfa Laval Corporate AB. Alfa Laval Corporate AB will enforce its rights related to this document to the fullest extent of the law, including the seeking of criminal prosecution.